

BCN3D 3D-printeri hooldus

3D-printeri hoolduse soovitame jälgida ajalist plaani:

FREQUENCY	ACTION TO PERFORM
Daily	Keep the printer free of dust and in a dry, cool place Storage the spools in a dry, cool place Remove the filament inside the Purge Tank Remove the filament leftovers spread inside the printer
Weekly	Clean the glass printing surface with warm water and soap Clean the nozzles Level the printing surface glass (also after a transportation)
Monthly	Clean fans dust Printer calibration (also after a transportation or replacing a hotend) Check firmware updates
Quarterly	Check bolted and threaded joints Clean and lubricate axes Check tension of extruder springs Check X/Y belt tension Check connections of moving cables

Hoolduse käiguse tehtavate tegevuste täpsema kirjelduse saate järgmisest dokumendist:



User_Guide_Sigma_R
19.pdf

Lisame veelgi kergemaks BCN3D 3D-printeri hooldamiseks YouTube lindi:

<https://www.youtube.com/watch?v=3WyDHIKiByI&list=PL8iOVmTsyyGRfqdhiidUTjZNIWitiLi6H>

3D-printeri hoolduse kirjeldus tootja BCN3D kodulehelt:

<https://support.bcn3d.com/knowledge>

Vajalikud vahendid 3D-printeri hoolduseks ikka meie e-poest:

<http://www.3dprinter.ee/et/c/tarvikud>

Kui Te ei leia meie e-poest soovitud toodet siis palun kirjutage meil ja saame Teid nõustada e-maili teel.

Head 3D-printimist!

BALTAL meeskond

www.3dprinter.ee

www.3dprinting.ee